## § 25.1583

complexity of the manual indicates a need for it.

[Amdt. 25–42, 43 FR 2323, Jan. 16, 1978, as amended by Amdt. 25–72, 55 FR 29786, July 20, 1990]

## §25.1583 Operating limitations.

- (a) Airspeed limitations. The following airspeed limitations and any other airspeed limitations necessary for safe operation must be furnished:
- (1) The maximum operating limit speed  $V_{MO}/M_{MO}$  and a statement that this speed limit may not be deliberately exceeded in any regime of flight (climb, cruise, or descent) unless a higher speed is authorized for flight test or pilot training.
- (2) If an airspeed limitation is based upon compressibility effects, a statement to this effect and information as to any symptoms, the probable behavior of the airplane, and the recommended recovery procedures.
- (3) The maneuvering speed  $V_A$  and a statement that full application of rudder and aileron controls, as well as maneuvers that involve angles of attack near the stall, should be confined to speeds below this value.
- (4) The flap extended speed  $V_{FE}$  and the pertinent flap positions and engine powers.
- (5) The landing gear operating speed or speeds, and a statement explaining the speeds as defined in §25.1515(a).
- (6) The landing gear extended speed  $V_{LE}$ , if greater than  $V_{LO}$ , and a statement that this is the maximum speed at which the airplane can be safely flown with the landing gear extended.
- (b)  $Powerplant\ limitations.$  The following information must be furnished:
- (1) Limitations required by §25.1521 and §25.1522.
- (2) Explanation of the limitations, when appropriate.
- (3) Information necessary for marking the instruments required by §§ 25.1549 through 25.1553.
- (c) Weight and loading distribution. The weight and center of gravity limits required by §§ 25.25 and 25.27 must be furnished in the Airplane Flight Manual. All of the following information must be presented either in the Airplane Flight Manual or in a separate weight and balance control and loading

document which is incorporated by reference in the Airplane Flight Manual:

- (1) The condition of the airplane and the items included in the empty weight as defined in accordance with §25.29.
- (2) Loading instructions necessary to ensure loading of the airplane within the weight and center of gravity limits, and to maintain the loading within these limits in flight.
- (3) If certification for more than one center of gravity range is requested, the appropriate limitations, with regard to weight and loading procedures, for each separate center of gravity range.
- (d) Flight crew. The number and functions of the minimum flight crew determined under §25.1523 must be furnished.
- (e) *Kinds of operation*. The kinds of operation approved under §25.1525 must be furnished.
- (f) Altitudes. The altitude established under § 25.1527.
  - (g) [Reserved]
- (h) Additional operating limitations. The operating limitations established under §25.1533 must be furnished.
- (i) Maneuvering flight load factors. The positive maneuvering limit load factors for which the structure is proven, described in terms of accelerations, must be furnished.

[Doc. No. 5066, 29 FR 1891, Dec. 24, 1964, as amended by Amdt. 25–38, 41 FR 55468, Dec. 20, 1976; Amdt. 25–42, 43 FR 2323, Jan. 16, 1978; Amdt. 25–46, 43 FR 50598, Oct. 30, 1978; Amdt. 25–72, 55 FR 29787, July 20, 1990]

## §25.1585 Operating procedures.

- (a) Information and instructions regarding the peculiarities of normal operations (including starting and warming the engines, taxiing, operation of wing flaps, landing gear, and the automatic pilot) must be furnished, together with recommended procedures for—
- (1) Engine failure (including minimum speeds, trim, operation of the remaining engines, and operation of flaps);
- (2) Stopping the rotation of propellers in flight;
- (3) Restarting turbine engines in flight (including the effects of altitude):